

車底／傳動工具 UNDERCAR SERIES



1404A
圓盤型避震器彈簧壓台
SPRING COMPRESSOR
STAND



4151
A臂避震器彈簧壓縮器
COIL SPRING
COMPRESSOR
(WISHBONE
SUSPENSION)



4063
1941用保護套
PROTECTIVE COVERS
OF JTC-1941



4064
1941用大C型配件
EXTRA LARGE C DISC
OF JTC-1941



4065
1941用圓型配件
EXTRA LARGE ROUND
DISC OF JTC-1941



1941
免拆式避震彈簧
壓縮器
INTERCHANGEABLE
-FORK SPRING
COMPRESSOR



4274
強力型避震彈簧
壓縮器
HEAVY DUTY
SPRING
COMPRESSOR



4135
磁式大王角水平儀
ANGLE LOCATOR



1230
調整型磁式水平錶
ANGLE LOCATOR



1955
立式彈簧壓縮器(口型)
SPRING COMPRESSOR
STAND



1956
立式彈簧壓縮器
(專利型)
SPRING
COMPRESSOR
STAND



1404S
圓盤型雙爪避震器
壓台
SPRING
COMPRESSOR
STAND
(2 JAWS)



4541
開口型固定座
撐開器(二支)
OPEN TYPE STEERING
KNUCKLE SPREADER
TOOL(TWIN)



F270
捲型彈簧壓縮器(短型)
DROP FORGED COIL
SPRING COMPRESSOR



1840
仰角校正器組
ALIGNMENT TOOLS



1323
綜合型避震器座
套筒組
UNIVERSAL STRUT
NUT TOOL SET



4021
手壓式培林注油機
HAND OPERATED
BEARING PACKER



4713
避震器油壓缸拆裝套筒
SHOCK ABSORBER
RAM DISMANTLE
SOCKET



4540
開口型固定座撐開器(單支)
OPEN TYPE STEERING
KNUCKLE SPREADER
TOOL(SINGLE)



F370
捲型彈簧壓縮器
(長型)
DROP FORGED COIL SPRING
COMPRESSOR



1401
爪式避震彈簧壓縮器
HEAVY DUTY COIL
SPRING COMPRESSOR



1030
培林注油器
UNIVERSAL
BEARING PACKER



4641
杯式培林注油器
BEARING PACKER



1002
雙A臂仰角校正器
ALIGNMENT TOOLS



6719
傳動軸外半軸拆卸器
CV JOINT
ASSEMBLY
REMOVAL TOOL



1241
輪弧擴張器
FENDER
EXTENDING TOOL



F1954
橫拉桿球頭拆卸器
(日規)
BALL JOINT
SEPARATOR



1336
窄型橫拉桿球頭
拆卸器
THIN TYPE BALL
JOINT SEPARATOR



4126
窄型加大型橫拉桿
球頭拆卸器
THIN TYPE LARGE
BALL JOINT
SEPARATOR



1727
橫拉桿球頭拆卸器
(歐規)
UNIVERSAL BALL
JOINT SEPARATOR



4661
加高型橫拉桿
球頭拆卸器
BALL JOINT
SEPARATOR(HIGH)



1914
雙用式橫拉桿
球頭拆卸器(小型)
UNIVERSAL BALL
JOINT PULLER



1915
雙用式橫拉桿
球頭拆卸器(大型)
UNIVERSAL BALL
JOINT PULLER



1036
兩爪活動橫拉桿
拆卸器
OUTER TIE ROD
REMOVER



F0416
插式橫拉桿
球頭拆卸器(小車)
THIN BALL JOINT
SEPARATOR(18mm)



F0412
插式橫拉桿球頭
拆卸器(大車)
BALL JOINT
SEPARATOR(24mm)



F0428
插式橫拉桿球頭
拆卸器(28mm)
BALL JOINT
SEPARATOR(28mm)



1129
大車橫拉桿球頭
拔卸器(小型)
**PITMAN ARM
PULLER**



1952
大車橫拉桿球頭
拔卸器(大型)
**PITMAN ARM
PULLER**



1247
立式橫拉桿球頭
拔卸器(19mm)
**BALL JOINT
SEPARATOR**



1329
防塵套束帶破壞鉗
**CV BOOT HOSE
CLAMP CUTTER**



立式橫拉桿球頭拔卸器(歐規)
BALL JOINT SEPARATOR

編號 Item	開口 Jaws open	開口深 Jaws deep
1257	23	25
1258	28	25



4190
立式橫拉桿球頭
拆卸器(加高)
**BALL JOINT
SEPARATOR(HIGH)**



4098
方向機舵桿扳手
(加大型)
**EXTRA LARGE INNER
TIE ROD TOOL**



1839
方向機舵桿扳手
(通用型)
**MULTI-PURPOSE
INNER TIE ROD TOOL**



1918
防塵套束裝鉗
(尖頭)
**CV BOOT CLAMP
PLIERS**



1531
防塵套束裝鉗
(可延長)
**CV BOOT CLAMP
PLIERS
(EXTENSION)**



1532A
防塵套束裝鉗
(強力型)
**CV BOOT CLAMP
PLIERS
(HEAVY DUTY)**



6748
雙向強力型
防塵套束裝鉗
**2-WAY HEAVY
DUTY CV BOOT
BAND PLIERS**



4069
輪軸無孔鋼圈鉗
**LOCKING RING
W/O EYELET
PLIERS**



4158
TOYOTA 傳動軸
螺母凹點拆裝器
**TOYOTA DRIVE
AXLE NUT
REMOVER/
INSTALLER**



1950
雙盤面方向盤
拆裝器
**STEERING
WHEEL
PULLER SET**



1943A
方向盤拆裝器
(綜合型)
**STEERING WHEEL
REMOVER/
LOCK PLATE
COMPRESSOR
SET**



1503
防塵套束裝鉗
(多功能型)
**CV BOOT CLAMP
INSTALLER**



1212
防塵套束裝鉗
(虎鉗式)
**CLIP-R COLLAR
PLIERS**



1546
防塵套束裝鉗
(萬向虎鉗式)
**HOSE CLAMP
PLIERS
(ANGLE TYPE)**



4459
歐系車球接頭
拆卸器組(4種規格)
**EUROPEAN CAR
BALL JOINT
REMOVER(4 SIZES)**



4075
更換型油壓球接頭
拔卸器
**CHANGEABLE
HYDRAULIC BALL
JOINT SEPARATOR**



立式雙柱型橫拉桿球頭拔卸器
BALL JOINT EXTRACTORS

編號 Item	A	B	C
1316	18mm	36mm	38mm
1317	23mm	45mm	47mm
1318	29mm	62mm	62mm
1319	40mm	82mm	76mm
1320	46mm	78mm	100mm



雙調整式橫拉桿球頭拔卸器
BALL JOINT SEPARATOR

編號 Item	A	MAX. B
4642	17mm	58mm
1916	22mm	62mm
4643	32mm	80mm
4644	45mm	90mm



4871
橫拉桿球頭安裝器
**BALL JOINT
INSTALLER**



6699
球接頭套管安裝器
**BALL JOINT BOOTS
INSTALLER**



6732
方向機舵桿扳手
(特大型)
**EXTRA LARGE
INNER TIE ROD
TOOL**



1217
扁型防塵套束裝鉗
CV BOOT CLAMP TOOL



1833
雙尺寸防塵套束裝鉗
CV BOOT CLAMP TOOL



4640
簡便型防塵套束裝鉗
(附切刀)
**CV JOINT BANDING
TOOL(WITH CUTTER)**



1503
防塵套束裝鉗
(多功能型)
**CV BOOT CLAMP
INSTALLER**




1212
防塵套束裝鉗
(虎鉗式)
**CLIP-R COLLAR
PLIERS**



1546
防塵套束裝鉗
(萬向虎鉗式)
**HOSE CLAMP
PLIERS
(ANGLE TYPE)**



4873
五孔輪軸拆裝器
**HUB PULLER &
SEPARATOR**



4043
可變型防塵套束裝鉗(虎鉗式)
**FLEXIBLE HOSE CLAMP FOR
CLIP-R TYPE**



4563
四、五孔輪軸拆卸器
4 & 5 HOLES HUB PULLER

1619
傳動軸滑鏈組(C型盤)
INNER CV JOINT
PULLER

1016
傳動軸滑鏈組
(C型盤大)
INNER CV JOINT
PULLER

1802
傳動軸滑鏈組(方型盤)
FRONT WHEEL
DRIVE AXLE PULLER

1628
輪軸滑鏈組(五孔)
HUB SLIDE
HAMMER PULLER

1629
輪軸滑鏈組(四孔)
HUB SLIDE
HAMMER PULLER

4816
歐式五孔輪軸滑鏈組
HUB SLIDE
HAMMER PULLER

1145
通用型滑鏈組
(雙盤)
UNIVERSAL
AXLE SLIDE
HAMMER SET

4817
特大型五孔輪軸滑鏈組
HUB SLIDE
HAMMER PULLER
(OUTSIZE HAMMER)

4920
特大型四孔輪軸
滑鏈組
4 HOLE HUB SLIDE
HAMMER PULLER
(OUTSIZE HAMMER)

4920S
特大型輪軸滑鏈組
(雙盤面)
HUB SLIDE
HAMMER SET
(OUTSIZE HAMMER)

4592
加大盤特大型
輪軸滑鏈組
HUB SLIDE
HAMMER PULLER
WITH ENLARGED
PLATE(OUTSIZE
HAMMER)

4591
加大盤輪軸
拔卸器(油壓式)
HUB PULLER
WITH ENLARGED
PLATE
(HYDRAULIC)

4590
加大盤輪軸拔卸器
HUB PULLER WITH
ENLARGED PLATE

5431
11PCS 外四凸點
套筒組
11PCS GROOVED
NUT SOCKET SET
(OUTER TOOTH)

4465
六孔輪軸
拆卸器
6 HOLE HUB
SEPARATOR

4067
三爪輪軸培林
內緣拆卸器
3 JAW WHEEL
BEARING
REMOVER

4133
SUZUKI 前輪軸
套筒(JIMNY)
SUZUKI FRONT
WHEEL NUT
SOCKET(JIMNY)

1014
金吉星 傳動軸
套筒(圓孔)
AXLE NUT
SOCKET

1210
金吉星 傳動軸
套筒(八點)
AXLE NUT
SOCKET

6728
FORD TRANSIT
後輪軸套筒
FORD TRANSIT
REAR AXLE NUT
SOCKET

4466S
前輪軸拆解
工具組
FRONT WHEEL
HUB REMOVAL
TOOL SET

4890
斜型培令套
按裝器(小型)
BEARING RACE &
SEAL DRIVER SET

1611A
10PCS 斜型
培令套按裝器
10PCS BEARING
RACE & SEAL
DRIVER SET

1001A
25PCS 仰角
培林拆裝器
(附培林)
25PCS FWD FRONT
WHEEL BEARING
TOOL (WITH
BEARING)

4885
仰角培令用
油壓配件
HYDRAULIC WHEEL
BEARING TOOL
ASSORTMENTS

4492
更換型輪軸培林
拆裝器
UNIVERSAL HUB
BEARING REMOVER
/INSTALLER

5432
10PCS 內四凸點
套筒組
10PCS GROOVED
NUT SOCKET SET
(INNER TOOTH)

4479
JAGUAR 輪軸
螺帽套筒
JAGUAR AXLE
BEARING NUT
SOCKET

4482
CITROEN, PEUGEOT
球接頭套筒
CITROEN, PEUGEOT
BALL JOINT
SOCKET

4589
TOYOTA HIACE
傳動軸套筒
TOYOTA HIACE F
RONT WHEEL
BEARING NUT
SOCKET

1259
三爪式輪軸拔卸器
UNIVERSAL HUB
PULLER

1843
內孔培林滑鏈組
BLIND HOLE
BEARING PULLER
SET

4672
雙用型內孔培林
拔卸器
INTERNAL BEARING
REMOVER SET

4522
加大型內孔培林
拆卸配件組
ENLARGED
INTERNAL BEARING
REMOVER
ACCESSORIES

1146
三爪內、外孔培令
滑鏈組
3 JAW INTERNAL &
EXTERNAL PULLER
SET

1351
雙柱型培林拆卸器
DOUBLE SHAFT
BEARING REMOVER

5341
三爪內孔培林
拔卸器
3 JAW INTERNAL
BEARING REMOVER
SET

4306
FORD 輪軸培林拆裝組(78mm)
FORD WHEEL HUB
BEARING TOOL SET(78mm)

4307
FORD 輪軸培林拆裝器(82mm)
FORD WHEEL HUB
BEARING TOOL SET(82mm)

培令拆卸器
BEARING SEPARATOR

編號 Item	本體螺孔尺寸 Body Thread
9000	3/8" x 16 UNC
9005	3/8" x 16 UNC
9015	1/2" x 13 UNC
9025	5/8" x 11 UNC
9035	3/4" x 10 UNC

1141
小型培令拆卸組
(雙盤)
DUAL BEARING SEPARATOR KIT

1142A
中型培令拆卸組
BEARING SEPARATOR KIT

1142P
1142用特長型
延長接棒
EXTRA LONG EXTENSION BAR FOR JTC-1142

1143
大型油壓式培令
拆卸組
HYDRAULIC BEARING SEPARATOR PULLER KIT

1144
特大型H型培令
拆卸組
BEARING SEPARATOR PULLER KIT

1035
綜合型油壓拆卸器
HYDRAULIC GEAR PULLER SET

4704
油壓式鐵套
拆裝器(通用型)
UNIVERSAL HYDRAULIC BUSH EXTRACTOR

4705
油壓式鐵套拆裝器
(H型支架)
PRESS FRAME FOR HYDRAULIC EXTRACTOR

4831
油壓式鐵套拆裝器
(加大配件組)
HYDRAULIC BUSH EXTRACTOR (EXTRA LARGER PARTS)

4855
鐵套, 培林, 油封
拆裝套件組(大型)
EXTRA LARGE CUSTOM BUILT BUSH/BEARING/ SEAL DRIVER SET



1559
HONDA
游臂鐵套拆裝組
HONDA REAR TRAILING ARM BUSH REMOVER/INSTALLER



6729
FORD TRANSIT
下游臂鐵套工具
FORD TRANSIT LOWER CONTROL ARM BUSH TOOL

4651
FORD 鐵套拆裝器
FORD REAR SUSPENSION BUSH TOOL

6647
FORD, MAZDA
游臂鐵套拆裝器
FORD, MAZDA REAR TRAILING ARM BUSH REMOVER/INSTALLER

4528
FORD, MAZDA,
VOLVO 游臂鐵套
拆裝器
FORD, MAZDA, VOLVO REAR TRAILING ARM BUSH REMOVER/INSTALLER

6627
FORD, VOLVO
游臂鐵套拆裝器
FORD, VOLVO REAR AXLE TRAILING ARM BUSH REMOVER/INSTALLER

4856
鐵套, 培林, 油封
拆裝套件組 (小型)
CUSTOM BUILT BUSH/ BEARING/SEAL DRIVER SET

4091
螺桿式鐵套拆裝器
(通用型)
UNIVERSAL BUSH REMOVE AND INSTALL SLEEVE SET

6770
29PCS螺桿式
鐵套拆裝組
29PCS SCREW PIVOT BUSH REMOVER/INSTALLER

4650
OPEL, VAUXHALL
鐵套拆卸器
OPEL, VAUXHALL REAR SUSPENSION BUSH REMOVAL TOOL

6650
OPEL, VAUXHALL
後仰角鐵套拆裝器
OPEL, VAUXHALL REAR AXLES BUSH REMOVER/INSTALLER

4164A
TOYOTA
工字樑鐵套拆裝器
TOYOTA SUB-FRAME BUSH REMOVER/INSTALLER

6729
FORD TRANSIT
下游臂鐵套工具
FORD TRANSIT LOWER CONTROL ARM BUSH TOOL

4651
FORD 鐵套拆裝器
FORD REAR SUSPENSION BUSH TOOL

6647
FORD, MAZDA
游臂鐵套拆裝器
FORD, MAZDA REAR TRAILING ARM BUSH REMOVER/INSTALLER

4528
FORD, MAZDA,
VOLVO 游臂鐵套
拆裝器
FORD, MAZDA, VOLVO REAR TRAILING ARM BUSH REMOVER/INSTALLER

6627
FORD, VOLVO
游臂鐵套拆裝器
FORD, VOLVO REAR AXLE TRAILING ARM BUSH REMOVER/INSTALLER

J01
碟式剎車調整器
DISC BRAKE PISTON SEPARATOR

1405
蝶式剎車調整器
(四活塞)
DISC BRAKE PISTON COMPRESSOR (4 PISTONS)

6757
更換式剎車分泵
調整器
CHANGEABLE DISC BRAKE PISTON COMPRESSOR

4165
簡易型剎車分泵組
BRAKE CALIPER ADJUSTER

1613A
15PCS
剎車分泵調整組
15PCS CALIPER WIND BACK KIT

1452A
21PCS 正反牙
剎車分泵調整組
21PCS POSITIVE & NEGATIVE CALIPER WIND BACK KIT

4687
氣壓式剎車分泵調整組
AIR CALIPER WIND BACK KIT

4468
剎車盤量測工具組
BRAKE DISC RUN-OUT KIT

4204
剎車分泵活塞
拆卸器
UNIVERSAL CALIPER PISTON REMOVER

4564
剎車來令片量測規
BRAKE SHOE GAUGE

1708
鼓式剎車彈簧車司
拆裝器
BRAKE SPRING COMPRESSOR

4487
TOYOTA
後手剎車彈簧起子
TOYOTA REAR HANDBRAKE SPRING DRIVER

1709
鼓式剎車來令片
彈簧拆裝器
BRAKE SPRING TOOL

4323
剎車盤/輪胎深度量規
BRAKE DISC & TYRE DEPTH GAUGE

4269
鼓式剎車彈簧車司
拆裝鉗
BRAKE SPRING WASHER PLIERS



4270
剎車彈簧拆裝器
BRAKE SPRING
TOOL



1944
T型剎車彈簧拉鉤
HEADLIGHT
ADJUSTING
AND BRAKE
SPRING HOOK



6735
歐系車輪殼清除器
WHEEL HUB
GRINDER FOR
EUROPEAN CARS



1541
14PCS 輪殼
清除器組
14PCS
WHEEL HUB
RESURFACING
KIT



1511
剎車分泵槽溝
清潔器組
BRAKE CYLINDER
GROOVE CLEANER



1365
5角凸頭套筒(10mm)
PANTAGON SOCKET
BIT DRIVER(10mm)



4725
一字起子套筒(24mm)
SLOTTED SOCKET
(24mm)



4731
10 角氣動套筒(20mm)
10 POINT IMPACT
SOCKET(20mm)



6651
剎車油管彎曲
校正器
BRAKE OIL PIPE
STAPLE TOOL



1353
手剎車鋼索拆裝鉗
CENTER BRAKE
LEVER ASSEMBLE
& DISASSEMBLE
PLIERS



4880
剎車卡鉗座螺牙
再生器
BRAKE CALLIPER
GUIDANCE
THREAD
REPAIR SET



4660
2PCS 排氣管橡膠墊
拉鉤組
2PCS RUBBER
RING HOOK
TOOL SET



4868
排氣管橡膠墊拆卸鉗
EXHAUST PIPE
HANGER
STRETCHER



4663
排氣管C型夾拆裝器
EXHAUST SPRING
CLAMP REMOVER/
INSTALLER



4057
排氣管分離器
2PCS EXHAUST
PIPE REMOVER



4039
排氣管切斷器
RATCHET
EXHAUST
PIPE CUTTER



4319
排氣管擴張器
EXHAUST PIPE
EXPANDER



4049
方向盤、剎車
踏板固定器
STEERING
WHEEL &
PEDAL
HOLDER



6614ST
輪軸搖晃測試器
STEERING AND
SUSPENSION
INDICATOR



7709
輪胎拔釘鉗
TIRE NAIL
REMOVER



3922
補胎條用補胎針
(鐵柄)
METAL T HANDLE
CLOSED EYE TOOL



39221
補胎針頭
TIP OF METAL T HANDLE
CLOSED EYE TOOL



3922L
補胎條用補胎針
(加長型)
METAL T HANDLE
CLOSED EYE TOOL



3922L1
補胎針頭(加長型)
TIP OF METAL T HANDLE
CLOSED EYE TOOL



3923
補胎條用補胎鑽
(鐵柄)
METAL T HANDLE
RASP EYE TOOL



39231
補胎鑽針頭
TIP OF METAL T HANDLE
RASP EYE TOOL



5807
省力型補胎針工具
EFFORT-SAVING
CLOSED EYE TOOL



4219
8PCS 小車輪胎
定位桿組
WHEEL STUD
ALIGNMENT
GUIDE TOOL



1911
輪胎鉛子鉗
WHEEL WEIGHT
TOOL



3928
補胎滾輪工具
ROLLER
STITCHER



3460
木柄補胎滾輪工具
ROLLER
STITCHER

補胎片
ROUND TUBE PATCH

編號 Item	直徑 Size	包裝 Packing
5307	φ32	100pcs(in one inner box) / 100 boxes(in one carton)
5308	φ42	50pcs(in one inner box) / 100 boxes(in one carton)



3429
補胎膠水
RUBBER CEMENT
FOR TIRE SEAL



3430
補胎條
TIRE SEAL



3431
補胎條工具組
TIRE SEAL
TOOL SET



4055
強力型橫桿拉拔器
WISHBONE
EXTRACTION
TOOL



1733
輪胎深度規
TIRE CONSUMPTION
GAUGE



5150
圓表型輪胎深度規
TIRE GAUGE(ROUND)



5328
數字型輪胎深度規
DIGITAL TIRE
CONSUMPTION
GAUGE



4454
10PCS 胎壓偵測器
拆裝組
10PCS TIRE PRESSURE
SENSOR REMOVER/
INSTALLER SET



3926
氣門風嘴拉拔器
SNAP IN TIRE
VALVE
INSTALLER



5630
2PCS 輪胎拆卸
保護墊
RIM PROTECTOR



5631
4PCS 輪胎撬棒組
4PCS TIRE
LEVER SET



7707
防傷型輪胎撬棒
RIM PROTECTIVE
TIRE PRY BAR

輪胎打氣頭 AIR CHUCK

編號 Item	全長 Length	頭部內徑 Head I.D.	入風牙規 Input thread	手柄 Handle
5607	150mm	8mm	1/4"PT	Metal
5608	205mm	8mm	1/4"PT	Rubber
5609	350mm	8mm	1/4"PT	Rubber

**扭力型氣門心起子
VALVE CORE TORQUE TOOL**

編號 Item	設定扭力 Range of the torque	適用風嘴 Valve type	顏色 Color
3523	25N.cm/2 lbf.in(±6%)	RUBBER	Red
3524	45N.cm/4 lbf.in(±8%)	METAL	Black

**氣門心起子
VALVE CORE REMOVER/INSTALLER TOOL**

編號 Item	長度 Length	直徑 Diameter	編號 Item	長度 Length	直徑 Diameter
3932	60mm	φ 4.5mm	3932L	160mm	φ 4.5mm

**強力附磁氣門心起子
HEAVY DUTY MAGNET VALVE CORE TOOL**

編號 Item	長度 Length	直徑 Diameter	編號 Item	長度 Length	直徑 Diameter
7721	60mm	φ 4.5mm	7721L	160mm	φ 4.5mm



6769
經濟型三用打氣
量壓表
3-FUNCTION
TIRE GAUGE



6726
數字型三用打氣
量壓表
DIGITAL 3-
FUNCTION TIRE
GAUGE



4236
輕量型三用打氣
量壓表(精準型)
LIGHTWEIGHT 3-
FUNCTION TIRE
GAUGE
(ACCURATE TYPE)



4058
輕量型三用打氣
量壓表(夾式)
LIGHTWEIGHT 3-
FUNCTION TIRE
GAUGE(CLIP TYPE)



4058L
輕量型三用打氣
量壓表(壓式)
LIGHTWEIGHT 3-
FUNCTION TIRE
GAUGE(PRESS TYPE)



4514
煮沸式剎車油
測試器
BOIL TEST BRAKE
FLUID ANALYZER



1538A
剎車油測試器
POCKET BRAKE
FLUID TESTER



6755
6PCS 更換扳手型
剎車油洩油管
6PCS CHANGEABLE
WRENCH TYPE
BRAKE BLEEDER



**扳手型剎車油
洩油管
BRAKE BLEEDER**

編號 Item	規格 Spec	編號 Item	規格 Spec
420707	7mm	420711	11mm
420708	8mm	420712	12mm
420709	9mm	420703	3/8"
420710	10mm		



1020
10L 手動式抽油機
HAND OPERATED
FLUID EXTRACTOR
(10L)



1050
手氣動抽油機(雙用)
PNEUMATIC &
HAND OPERATED
FLUID EXTRACTOR



1045
6.5L 手動式抽油機
HAND
OPERATED
FLUID
EXTRACTOR
(6.5L)



1023A
氣動式抽油機
PNEUMATIC
FLUID
EXTRACTOR



1024
氣動式加油機
(吸加兩用)
PNEUMATIC
OIL & LIQUID
DISPENSER



1025
氣動式剎車油
吸取機
PNEUMATIC
BRAKE BLEEDER



1026
剎車油補充油壺組
BRAKE OIL
FILLER



4810
軟管型剎車
補充油壺
TUBE BRAKE OIL
FILLER



5440
手拉式吸加油槍
(鐵管)
HAND OPERATED
FLUID SYRINGE
(METAL)



**手拉式吸加油槍
HAND OPERATED FLUID SYRINGE**

編號 Item	容量 Capacity	桶身尺寸 Tube size	適用油品 Applications
5533	200 C.C.	φ 47 x 210 mm	Brake fluid, antifreeze/ coolant
5534	1500 C.C.	φ 90 x 360 mm	engine oil, gear oil, transmission oil



4634
指針式機油流量表
CLOCK FLOW
METER



4635
電子式機油流量表
DIGITAL FLOW
METER



1033
手壓機油桶
HAND
OPERATED
OIL PUMP



4632
25L 氣動式加油機
PNEUMATIC OIL
FILLING
MACHINE(25L)



4328
塑膠桶手壓
機油桶
PLASTIC HAND
OPERATED
OIL PUMP



4633
80L 氣動式加油機(吸加兩用)
VACUUM & PNEUMATIC OIL
FILLING MACHINE(80L)



4144A
ATF 手壓式加油機
HAND OPERATED
ATF FLUID
DISPENSER



4252
ATF 氣動式加油機
(吸加兩用)
10L PNEUMATIC
ATF & LIQUID
DISPENSER



4539
ATF 壓差式加油機
ATF
DIFFERENTIAL
PRESSURE
REFUELING
MACHINE



6624
ATF 新型接頭組
(8PCS)
ATF EXTRA
ADAPTER SET(8PCS)



4253
200L
氣動式機油機
200L
PNEUMATIC
OPERATED
OIL PUMP



4876
50加侖氣動式
抽油機
PNEUMATIC
PISTON OIL &
LIQUID PUMP

黃油軟管
FLEXIBLE GREASE TUBE

編號Item	長度 Length	工作壓力 Working Pressure
3307	12" (300mm)	4500 psi
3308	18" (450mm)	4500 psi



3305
手壓黃油槍
HAND
GREASE GUN



3306
氣動黃油槍
AIR
GREASE GUN



5551
連發氣動黃油槍
REPEATING AIR
GREASE GUN



4254
200L
氣動式黃油機
200L PNEUMATIC
OPERATED
GREASE PUMP



4548
手壓式黃油桶
HAND OPERATED
GREASE PUMP



1034
氣動黃油機
AIR OPERATED
GREASE PUMP



1031
80L 廢油桶
WASTE OIL DRAIN



1512
分離式
抽漏廢油桶
SEPARATED TYPE
VACUUM OIL
DRAINER



4819
氣壓式抽漏廢油桶
VACUUM OIL
DRAINER &
EXTRACTOR



1032
真空式抽油機(附抽剎車油)
VACUUM OIL EXTRACTING
MACHINE & BRAKE
BLEEDER



4332
電動式
剎車油交換機
ELECTRIC BRAKE
BLEEDER



6737
BENZ 雨刷噴嘴調整器
BENZ WINDSHIELD
WASHER NOZZLE
ADJUSTER



6646
BENZ 頭燈角度調整器
(W205)
BENZ HEADLIGHT
ADJUSTER(W205)



4046
BENZ 油心蓋扳手
(46mm)
OIL FILTER WRENCH
(46mm)



1702
BENZ 風扇扳手
(36mm)
FAN CLUTCH TOOL
(36mm)



1715
BENZ 風扇扳手
(65mm)
FAN CLUTCH TOOL
(65mm)



1713
BENZ 風扇支撐板手
(L型)
FAN CLUTCH
HOLDER



1714
BENZ 風扇支撐板手
(三孔)
FAN CLUTCH
HOLDER



1832
BENZ 風扇扳手
FAN BELT SERVICE
WRENCH



1313
BENZ, BMW
風扇板手組
FAN CLUTCH
TOOL SET



6611
BENZ 後保險桿套筒
(8mm)
BENZ REAR BUMPER
SOCKET(8mm)



4213
BENZ 後保險桿套筒
(10mm)
BENZ REAR BUMPER
SOCKET(10mm)



1123
BENZ 鎖頭外框套
拆卸器
IGNITION LOCK
REMOVER



4691
BENZ 鎖頭拆卸器
IGNITION LOCK
REMOVER